


Dr. Brown's® MilkSPA™

QUICK REFERENCE GUIDE

Before first use, review Instruction Manual for full warnings & detailed instructions.

EASY SETUP

1. Check that the warmer is unplugged.
Remove gray warming basket and unlock the warming chamber by twisting counterclockwise and lifting from base.
2. Add water to fill line on inner rim, indicated by the arrow - approximately 10oz/300ml of water.
3. Place warming chamber onto base, aligning arrow with unlock symbol (on the back of the base) and twist clockwise to align arrow with lock symbol. Insert gray warming basket. Plug in.



SIMPLE SETTINGS

1. Place bottle, bag, pouch or jar into warming basket.
Press any button to light screen.
2. To access all container options, start in the refrigerator setting by pressing the temperature button until the refrigerator symbol appears on screen.
Then select your custom warming cycle:



Type of Container



by pressing the vessel button to choose between plastic bottle, glass bottle, or storage bag.



Volume

by pressing the up and down arrows to adjust the number of ounces.

Starting Temperature



by pressing the temperature button to choose between frozen, refrigerated, or room temperature.



If at any point you need to get back to all container options, simply repeat step 2.



3. Press the start button.

Dr. Brown's® MilkSPA™

HELPFUL HINTS

Before first use, review Instruction Manual for full warnings & detailed instructions.

Safely warming baby's meal is convenient with Dr. Brown's MilkSPA™, featuring 12+ settings to warm baby's milk and food from any temperature.

The preprogrammed settings are a great starting point, but the exact time needed for warming can be affected by many factors. After selecting your custom setting, use the up and down buttons to adjust the timer as needed.

Memory Function: the last setting that was started will be displayed the next time the warmer is turned on. Simply press start to repeat that cycle.

- To prevent pressure from building up, Dr. Brown's® bottles need to have the vents removed before warming. A storage cap has been provided to seal your bottle after removing the nipple, collar, and vent system.
- Check that all bottles, bags and pouches are tightly sealed to prevent leaking.
- Read instructions on food jars before warming; some brands advise against warming in the jar. Do not use jars that have been opened.
- Water can be reused for up to 5 cycles or for one day's time (whichever comes first). At that point, water should be replaced. Distilled water is recommended for easiest cleaning.
- MilkSPA™ may be used without the gray warming basket for larger bottles & bags, but smaller containers will warm better with the basket in place.
- In the settings, glass bottles do not have a frozen option & storage bags do not have a room temp option.
- To switch between ounces and milliliters, hold down the vessel button for three seconds.
- MilkSPA™ will beep when the cycle is complete and will shut off. Removing the container right away prevents the milk/food from continuing to warm.
- CAUTION Always check the temperature of the milk or food before feeding baby.

For additional Dr. Brown's MilkSPA™ resources visit drbrownsbaby.com

or reach out to our helpful Customer Service team at

info@handi-craft.com & 1-800-778-9001.